avenlur

Betula by Avenlur

Need Help?

CALL US AT 888.697.3931 / M-F 9AM - 5PM PT (12PM - -8PM ET)
OR EMAIL US AT INFO@AVENLUR.COM

V2-79

⚠ WARNING

Adult assembly required.

⚠ WARNING

Maximum user weight: 220 lbs (100kg) per child.

⚠ WARNING

⚠ CHOKING HAZARD:

Adult assembly required. Keep small assembly parts out of reach of children.

⚠ Use under adult supervision.

OBSERVE ALL STATEMENTS AND WARNINGS TO REDUCE THE LIKELIHOOD OF SERIOUS OR FATAL INJURY. SAVE THIS SHEET FOR FUTURE REFERENCE.

OPERATION INSTRUCTIONS

1. An adult should always supervise use of this product by children of all ages.
2. Instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment (examples: ropes, clothesline, pet leashes, cables and chain, etc) as they may cause a strangulation hazard or any other hazard.
3. Never allow children to use the equipment in a manner other than intended.

MAINTENANCE INSTRUCTIONS

1. Inspect the product periodically for loose or damaged components. **Tighten bolts if need**.
2. Check all connections and bolts for tightness at least twice monthly during the usage.
3. Check all coverings and bolts for sharp edges.

INSTALLATION INSTRUCTIONS

Please have an electrical drill available for assembly if possible.
If you have difficulty in installation, please contact us for help and get installation video for reference.

Please Ensure:

1. You are assembling with at least two people to ensure that all sides and parts are leveled.
2. You don't screw the parts in too hard or it will splinter the wood.
3. You follow the directions carefully.

CONTACT US BEFORE ASSEMBLY IF:

- You need assistance with assembly

- You need a replacement part due to a missing part or defective part

Call us at 888-697-3931 M-F 9AM-5PM PT

or email us at info@avenlur.com



1 x1 23.3in

2 x6 24.4in

3 x10 26.5in

4 x2 25.4in



5 x1 23.3in

6 x2

7 x1 39.4in

8 x1 39.4in

9 x1 39.4in

10 x1 39.4in

11 x3 29.1in

12 x6 2in



13 x2 45.3in



14 x1 45.3in



15 x1



16 x1

17 x2 51.2in

M6.3x40

A x50



M6x120 M6x20

B x12

M8x100

C x2

M8

D x4

M8

E x4

M10x40

F x4

G x4



M6x80

H x6



4mm

I x2

13mm

J x2

01-1

Note: Pay attention to all the black bubbled section markers. The manual may refer back to those later



C	M8x100	1
D	M8	2

E	M8	2
F	M10x40	2

J	13mm	2

02-1



C	M8x100	1
D	M8	2

E	M8	2
F	M10x40	2

J	13mm	2

03-1

Pro Tip: Using your fingers, screw in all (A) screws a little to hold everything in place before using an electric screw driver. Then using a manual screw driver, tighten each one.



The protruding end of the part (3) need to correspond to the hole of part (9) and part (10) when installed.

02-1

01-1



A	M6.3x40	28

04-1



03-1



B	M6x120 M6x20	12
J	4mm	2

05-1

Note: Use a studfinder and mark the wall where the center of the studs are. Studs are typically 16" apart. Measure the distance between your studs to confirm. Mark, level and drill pilot holes (13/64 or 7/32 bit) in the wall before attaching parts (11) with screws (H)



H	M6x80	6

06-1



The protruding end of the part (2) need to correspond to the hole of part (1) when installed



A	M6.3x40	12

07-1









08-1

Note: Check all connections and bolts for tightness at least twice monthly during use.

Do not use if screws are loose.



A	M6.3x40	10





For questions with assembly or replacement parts, please email us at: info@avenlur.com or call us at: 888-697-3931